



IT- GRATTUGINO & CUCCHIAIO IN SILICONE

- Grattugia in plastica ideale per preparare in pochissimo tempo puree di frutta e verdura squisite, fresche e naturali.
- Cucchiao in silicone super morbido per gengive delicate.



ISTRUZIONI PER L'USO LEGGERE QUESTE ISTRUZIONI E CONSERVARLE PER FUTURO RIFERIMENTO. AVVERTENZA!

- Utilizzare sempre questo prodotto sotto la sorveglianza di un adulto.
- Prima di ogni uso controllare il prodotto. Sostituirlo al primo segno di usura o danneggiamento.
- Questo prodotto può rompersi se cade.
- Controllare sempre la temperatura dell'alimento prima di alimentare il bambino.
- Pulire il prodotto prima del primo uso.
- Pulire sempre il prodotto subito dopo ogni utilizzo. Lavare a mano utilizzando un comune detergente per piatti.
- Non utilizzare mai spugne e/o detersivi abrasivi, antibatterici o solventi chimici.
- Risciacquare sempre il prodotto con acqua corrente dopo ogni lavaggio ed asciugarlo subito accuratamente, conservarlo in un luogo pulito ed asciutto, protetto dalla luce solare diretta e da fonti di calore.
- Il prodotto può essere lavato in lavastoviglie, impostando un ciclo di lavaggio delicato a bassa temperatura (max 45°). Tale tipo di lavaggio, più aggressivo, potrebbe deteriorare o scolorire con il tempo il materiale.
- Non appoggiare su superfici calde, piastre riscaldanti o fiamme libere.
- Non inserire il prodotto in forni a microonde o tradizionali.
- Questo prodotto non è un giocattolo, quando non in uso tenere fuori dalla portata del bambino.
- Tenere l'imballo e tutti i suoi componenti fuori dalla portata del bambino.

CUCCHIAIO IN SILICONE

- Non bollire e/o inserire il cucchiao in forno (tradizionale e/o microonde) o in alimenti eccessivamente caldi (max 40°).
- La parte morbida del prodotto potrebbe macchiarsi o cambiare colore assumendo quello degli alimenti con i quali viene a contatto e/o assorbirne l'aroma. Questo fatto non altera la funzionalità del prodotto e/o la sua sicurezza. Si consiglia di lasciare in contatto il prodotto nei cibi solo il tempo necessario per il pasto.
- Il silicone è un materiale che potrebbe lacerarsi, si raccomanda di prestare attenzione allo spuntare dei dentini del bambino.

GRATTUGIA

- La grattugia non è adatta come piattino per il bambino, spostare la purea in un contenitore idoneo.
- Non immergere in acqua bollente, negli sterilizzatori a vapore, non inserire nel forno microonde.
- Questo prodotto non è destinato alla conservazione dei cibi o al loro riscaldamento.
- Alimenti con colorazione intensa come ad esempio carote, barbabietole, scorze di limone o arance potrebbero macchiare il prodotto.

In caso di dubbi sull'interpretazione del contenuto delle presenti istruzioni contattare il rivenditore o Artsana S.p.A..

EN- BABY GRATER & SILICONE SPOON

- Plastic grater ideal for rapidly preparing fresh, tasty and natural fruit or vegetable purée.
- Extra soft silicone spoon for delicate gums.



INSTRUCTIONS FOR USE READ THESE INSTRUCTIONS AND KEEP FOR FUTURE REFERENCE. WARNING!

- Always use this product with adult supervision.
- Before each use, inspect the product. Throw away at the first signs of damage or weakness.
- This product may break if dropped.
- Always check food temperature before feeding.
- Clean the product before using for the first time.
- Always clean the product immediately after each use. Hand wash using ordinary dishwashing soap.
- Never use abrasive sponges and/or detergents, antibacterial products or chemical solvents.
- Always rinse the product in running water after each wash and dry thoroughly right away. Store in a clean, dry place away from direct sunlight and sources of heat.
- The product can be washed in the dishwasher, using a low-temperature (max 45°) gentle washing cycle. An aggressive type of washing may cause the material to deteriorate or discolour over time.
- Do not place on warm surfaces, hot plates or open flames.
- Do not put the product in microwaves or conventional ovens.
- This product is not a toy; when not in use, keep it out of the reach of children.
- Keep the packaging and all its components out of children's reach.

SILICONE SPOON

- Do not boil and/or insert the spoon in an oven (conventional and/or microwave) or in excessively hot foods (max 40°).
- The soft part of the product may stain or assume the colour of the foods with which it comes into contact and/or absorb their aroma. This does not alter the function and/or safety of the product. You are advised to leave the product in contact with foods only for the time necessary for the meal.
- Silicone is a material that may tear. You are advised to pay attention to the child's teeth as they come through.

GRATER

- The grater is not suitable for use as a child's plate. Transfer the puree to an appropriate container.
- Do not place in boiling water, steam sterilisers or the microwave.
- This product is not designed for storing or heating food.
- Foods with an intense colour, such as carrots, beets, lemon or orange peels, may stain the product.

If you have any doubts about these instructions please contact your retailer or Artsana S.p.A..



Grattugino & Cucchiao in Silicone Baby Grater & Silicone Spoon

6 m+

Puree exquisite e naturali subito pronte
Tasty natural purée ready immediately



Grattugino & Cucchiao in Silicone
Baby Grater & Silicone Spoon



Puree exquisite e naturali subito pronte
Tasty natural purée ready immediately



Grattugino & Cucchiao in Silicone
Baby Grater & Silicone Spoon



Puree exquisite e naturali subito pronte
Tasty natural purée ready immediately



REF. 00 009970 000 000
Artsana S.p.A. Via Saldarini Catelli, 1
22070 Grandate (Como) - Italy
www.chicco.com
GRATTUGIA, CUCCHIAIO: Made in Italy
GRATER, SPOON: Made in Italy
CUCCHIAIO, SPOON: EN 14372 Rev. 00-1842



8 058664 116911